


CONNECTIONS

Sensor Type	Serial coding	Connections			
		A	B	C	D
Any not requiring power	Sxxxx	√	√	-	-



A B C D

Switch POD

Item
10G30

CALIBRATION

None

WEB

On www.general-alert.com, login using Username and Password.

Options:

- Name the POD (Pressure Line A, Pond Level etc.)
- Set Alarm levels (On or Off **)
- Establish times of day and days of week for Alarm settings
- Establish Users to be notified on POD Alerts
- Obtain instant live Status Report from POD

Note - ** On or Off relates to the opening or closing of the switch device being used. "On" relates to a made circuit, "Off" relates to a broken circuit.

A trial may be needed to ascertain correct settings on the web.

MOBILE

To access features you need to be a listed User on a General Alert Account.

Features:

Receive Alerts

'Pond level' (S0003636) Alert:
Switch = OFF on Alarm 1.
(Normal = ON)

Cancel Alarm (while the problem is being sorted)

3636.0.2

Request Status Report for live data

3636.6

Receive Status Report

'Pond Level' (S0003636).
Reading = ON at 01 September
2011 08.45 (local time)

PO Box 103, Safron Walden, CB11 3GD, UK
T: +44 1799 550837, e: info@general-alert.com
W: www.general-alert.com