www.general-alert.com

 $\stackrel{\sim}{\sim}$ 



# **CONNECTIONS**

Sensor	Serial	Connections			
Type	coding	Α	В	С	D
PT100	Txxxx	white	white	red	red

Note - Erratic temperature readings will be recorded if the 4 wire connections A, B, C and D are not secure.



# Temp **POD**

Item 10G20

### **CALIBRATION**

None

On www.general-alert.com, login using Username and Password.

## **Options:**

Name the POD (Temp. Tank A, Cooling 25 etc.) Set Alarm levels (above or below specific temperatures) Establish times of day and days of week for Alarm settings Enable Daily Data Feed (for online graphing and recording) Establish Users to be notified on POD Alerts Obtain instant live Status Report from POD

### **MOBILE**

To access features you need to be a listed User on a General Alert Account.

### Features:

Receive Alerts

'Temp. Tank A (T0002224) Alert: Temp = 28.2 deg. onAlarm 2 (Normal = 28.1 deg.)

Cancel Alarm (while the problem

2224.0.2

is being sorted)

2224.6

Request Status Report for live data

Receive Status Report

'Temp. Tank A (T0002224). Reading = 20.6 at Aug 082010 16.45 (local time)

